

Quick Start Guide

Use your phone for more than just talking

- AT&T Navigator
- Media™ Net
- CV
- Mobile Email
- AT&T Mobile Music
- Downloadable Fun

See User Manual for Spanish Instructions

Additional charges may apply. Visit att.com for more details. Phone features subject to change without prior notice. All phone screens are simulated.

Services may not be available in all markets.

© 2008 AT&T Knowledge Ventures. All rights reserved. Subsidiaries and affiliates of AT&T Inc. provide products and services under the AT&T brand.

Getting to Know Your Phone



For more information visit att.com/DeviceSupport

AT&T Navigator

AT&T Navigator, with GPS enabled directions, is the fastest way to get where you are going - whether across town or across the country.

- From the idle screen, press . Select AT&T Navigator .
- Always find your way with turn-by-turn voice and on-screen directions.
- Find whatever you need on the road, including WiFi hotspots, restaurants, and business listings.
- Get where you're going faster! Save your favorite locations, get traffic updates, and one-click re-routing.

GPS works on a separate satellite signal than your wireless carrier.

For best results when using GPS services:

- Be outdoors and have a clear view of the sky. Hold the phone without blocking the antenna.
- Start AT&T Navigator and select a "Drive To" route before driving to acquire the initial GPS signal.
- Keep the device turned on to optimize subsequent uses of GPS.
- In some cases, acquiring the initial position may take up to 2-3 minutes.

CV


CV brings your phone to life. Watch news, sports, weather and entertainment clips while on the go.

1. From the idle screen, press the Right Soft Key for Main Menu.
2. Scroll to CV and press Center Select key .
3. Once connected, select the program options you wish to view and press Center Select key .
4. Select the clip you want to play and press Center Select key .

Personalize your CV content:

1. Select Customize CV from the CV home screen.
2. Select Edit My Favorites and press Center Select key .
3. Select the content you would like to appear on your CV Home screen and press Center Select key .

Parental Controls available. See box insert for details. CV requires a Media™ Max plan.



Optional Accessories

AT&T has accessories for productivity, convenience and fashion. You can also shop accessories at att.com/wireless.



Bluetooth® Headset H721



Battery



MicroSD Memory Card



Travel Charger



MOTOROKR™ S9 Bluetooth® Stereo Headphones



Vehicle Power Adapter





MOTOROKR™ T501

AT&T Mobile Music

AT&T Mobile Music provides the ultimate music experience with the push of the music button. Listen to your favorite music, watch the latest music videos, and stay in the know with music news and more.

From the idle screen, press the key.

- Browse and select music from leading digital music stores like Napster® and eMusic™ with **Shop Music**
- Listen to your music on an integrated **Music Player**
- Enjoy dozens of commercial-free music stations with **XM Radio**
- Watch the latest music videos under **Music Videos**
- Personalize with ringtones and Answer Tones™ under **Shop Music**
- Instantly ID the title and artist of a song with **MusicID** and purchase it through Napster®



Media™ Net

With Media Net, you can get the information that is important to you at a glance. Check local weather, your team scores or movie listings with just a few clicks.

1. From the idle screen, press Center Select key .
 2. Select for Media Net.
 3. Highlight the content you want to view and press the Center Select key .
- Weather
 - News
 - Sports... and more!


Personalize your Media Net Home screen:

1. From Media Net home screen, scroll to "Customize Media™ Net" and press Center Select key .
2. Select Edit Categories and press the Center Select key .
3. Highlight the categories you would like to appear on your Media Net home screen and press Save.

Mobile Email


Take your email with you. With Mobile Email, you can quickly and easily access your email if your account is with one of the following providers: Yahoo!®, AOL®/AIM, Windows Live™ Mail, or AT&T® Yahoo! among others.

1. From the idle screen, press the left Navigation key .
2. Scroll to the email carrier of your choice and press the Left Soft key to Select. Accept terms and conditions pressing Left Soft key , I agree.
3. Type in your personal Email address (e.g., "silverfox2"), then enter your account's Password and press the Sign In soft key.
4. You will be connected to your account's Inbox and contacts, where you can send and receive emails.



All providers may not be available on all devices. Yahoo! and the Yahoo! logo are trademarks and/or registered trademarks of Yahoo! Inc. AOL, America Online and the Triangle Logo are registered trademarks of America Online. Windows Live and the Windows logo are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.















Downloadable Fun

Whether you are into the latest hits or the classics, let your phone reflect your style with downloadable ringtones and Answer Tones™. Or entertain yourself with cool tools and games.

To access the AT&T Mall

1. From the idle screen, press the Center Select key .
2. Highlight AT&T Mall  and press the Center Select key .
3. Select Shop Tones, Shop Games, Shop Graphics, Shop Multimedia, Shop Applications, or Shop Videos and press the Center Select key .
4. When your web connection is established, choose a category and press the Center Select key .

To access cool tools and games on your device

1. From the idle screen, press the Center Select key .
2. Highlight My Stuff  and press the Center Select key .
3. Scroll to Games & Apps and press the Center Select key .
4. Select the game or application you would like to launch and press the Center Select key .
5. Follow the step by step instructions.



Warning! Do not disconnect phone while the transfer is in progress.

Requirement: Windows 2000 or later.

Not compatible with Mac OS.


Note: Not compatible with iTunes.


For additional information on transferring music, refer to the User Manual. Memory card is required to listen to music stored or downloaded to the device. The number of files you can store depends on the size and format options of the memory card (up to 8GB).

*USB cable and microSD card sold separately.

Transfer Music

Transfer music from your existing MP3 collection or from leading digital music stores like Napster® and eMusic™ to your phone. It's Simple.


1. Load music to your computer using Windows Media Player, Napster client, or music manager software.
2. Insert the microSD card* into the handset next to the SIM card behind the battery door.
3. With the USB cable* disconnected, verify that your Default Connection is set to Media Sync. From the idle screen, press the Right Soft Key  for Main Menu. Select Settings > Connection > USB Settings > Default Connection > Media Sync. Once verified this step can be skipped in the future.
4. Connect the USB cable* to your computer and the handset.
5. Once the USB cable is connected, your phone's memory card appears as a device where you can transfer or synchronize songs.
6. Highlight the track(s) you wish to download to the handset.
7. Using your right mouse button, click on the highlighted song and select "Add to Sync List" from the drop-down menu or drag them to the icon for your phone's memory card, and click on "Start Sync" (if applicable) to transfer the song in Windows Media Player or your preferred music manager software.




Play Music

Listen to music from your favorite artists right on your phone. To listen to music that you have transferred to your phone, follow these quick easy steps.

Playing Music on your Motorola Z9

1. Press the music key on the left side of the phone.
2. Search music by All Songs, Playlists, Artists, Albums, or Genres and press Center Select key  to select.
3. Press up or down on the navigation key to change the volume and the left or right navigation keys to go to the previous or next song.




Note: To view all pictures stored, in Idle mode press Center key -> Select My Stuff > Media Finder > press Pictures > All Pictures.

Take a Picture

Capture those special moments right from your phone and send them to friends and family. It's easy.

Take a Picture:

1. Press the Camera key located on the right side of the handset.
2. Adjust the image by aiming the camera at the subject.
3. Use the Navigation key for special effects such as zoom or lighting conditions.
4. Press the Center Select key  to take a picture.
5. Press Options to Store; Apply as Wallpaper/Screen Saver or Print.


To Send a Picture:

1. Press the Right Soft key  Send.
2. Press the Send To Right Soft key  to bring up the Address Book.
3. Highlight phone number and press Center key to select or enter own number, press Options > Enter Number.
4. Press Right Soft key  to Send.

Video Share

Share events the moment they happen. Video Share lets you stream live video directly to friends and family.

To make a Video Share call:


1. Dial the 10-digit number of another 3G Video Share capable device*
2. If the feature is available, the Video Share button will appear once the call is answered. Press the Right soft key  to initiate the Video Share session. The call will switch to speaker phone automatically.

To accept a Video Share call:

1. When receiving a Video Share call, the name or number of the person who wants to share video with you will appear on your screen.
2. Select Accept and the Video Share session will begin automatically.





To end a Video Share session and continue with the phone call, press Stop Video.




Note: Go to text messaging directly by pressing up with Navigation key .

Text Messaging

When you need to communicate privately and quickly, use text messaging. You can text message to other wireless phones and email addresses.

1. From the idle screen, press  > Select Messaging  > Select Create Message.
2. Type your message.
3. Press the Right Soft key  for Send To.
4. Enter the phone number of the person you wish to send your text message.
5. Press the Right Soft key  for Send, to send your message.






Note: When you receive an incoming instant message, a "new message" icon will appear on screen.

Instant Messaging


If you subscribe to an instant messaging service such as AIM®, Yahoo!® or Windows Media Live®, you can take the convenience and fun of instant messaging on the go with your wireless phone.

To choose your IM service:

1. From the idle screen, press Right Navigation key .
2. Highlight your IM Community and press the Center Select key .
3. The first time you enter a community, enter your Screen Name and your Password.
4. Press the Left Soft key  to select Done.

To use IM:

1. Once signed on, you're ready to send instant messages to your buddy list already set up with your IM service.



Note: If you get a call while in another task (except playing music), you can accept the call, then return to the task while you're talking.


Multitasking


Multitask simultaneously with voice and data – browse the web, make calls, send and receive messages, and listen to music. All at once.

While you're in a call:

1. Press the left soft key  to select Options.
2. Choose Select App for a list of available applications.

From your browser:

1. Press the left soft key  to select Options.
2. Select Open.
3. Select Swap for a list of available applications.



*Video Share is not available in all markets. Both parties must be in a 3G service area—a 3G icon must appear by the signal bars prior to a call being placed, and both parties must remain in the 3G coverage area for the duration of the Video Share session.